




502-921-0002

amishmadecabins.com

# APPLIANCE SIZE GUIDE




## MICROWAVE

If your plan calls for a cabinet for you to affix a microwave to, then it will be your standard 30 inch.



## RANGE

All cabins with range openings will accommodate a 30inch wide range unless otherwise notated and discussed between the customer and the cabin designer.



## REFRIGERATOR

Refrigerator openings for all cabin series are 36" except for the Rio Bravo series that is 30". If modifications are made, please verify with your cabin designer that the refrigerator opening has not changed as well.



## DISHWASHER

Not all cabin plans come with dishwasher openings, but those that do please refer to the following:

Dishwasher openings are set to fit a standard 24 inch dishwasher unless otherwise noted on the plan and asked for differently by the customer. The dishwasher opening will not have holes drilled for the drain line, but sinks will have a water cut off valve on the hot water line and we do install the outlet on for the designated switch.



## WASHER/DRYER

Depending on the cabin, you may have washer and dryer hookups notated on the plan. The space provided for the washer and dryer are set to accommodate standard size appliances. If you have a laundry center (stackable) , it will be drawn to fit your standard 29 inch wide stackable washer and dryer laundry center. If you have a space notated for a side by side it will be enough to accommodate two standard 29 inch wide appliances.



For over 20 years, we've been building and delivering cabins from our family to yours.

If you have any questions about our processes, or your cabin information, please let us know, we are always happy to help!